



QuickBrew Smooth Cold Brew Coffee and Tea Maker

Model: CB-175



Your satisfaction is guaranteed. If you are not completely satisfied with our QuickBrew, Smooth Cold Brew Coffee and Tea Maker and the results it brings, we insist that you let us know. We'll help make the Cold Brew Coffee & Tea Maker work for you, or we'll refund your money.


USER MANUAL

IMPORTANT SAFEGUARDS:

- READ ALL INSTRUCTIONS.
- This cold brew coffee and tea maker is intended for cold brewing, although it may be used to brew hot beverages up to 212°F (100°C).
- Only use the parts provided within this set. Using other unintended parts may damage the product or affect the effectiveness of the brew.
- Do not use a cracked glass carafe or water chamber.
- CAUTION! When full, the glass carafe can be heavy! Use a firm grip to hold.
- Always remove water chamber and filter before carrying carafe.
- DO NOT place any part of the brewer on or near a hot gas or electric burner or in a heated oven.
- DO NOT place glass carafe, filter, or water chamber into a microwave oven.
- DO NOT set the glass carafe on a wet surface.
- During the brewing process, make sure the brewing container is positioned in a safe area where it won't be knocked over or bumped. Make sure the lid is properly attached before moving a filled glass carafe. NOTE: DO NOT carry during the brewing process.
- Do not clean with harsh cleaners, steel wool pads, or other abrasive materials.

SAVE THESE INSTRUCTIONS FOR HOUSEHOLD USE ONLY

MEET YOUR QUICKBREW, SMOOTH COLD BREW COFFEE AND TEA MAKER



USING YOUR QUICKBREW, SMOOTH COLD BREW COFFEE AND TEA MAKER

BEFORE USING FOR THE FIRST TIME:

- 1 Remove all packing material.
- 2 Using warm water and dish soap, wash all the parts to remove any factory or packaging residue.
- 3 Rinse and dry all parts thoroughly with a clean dish-cloth or paper towel, or set aside to air dry.

BREWING INSTRUCTIONS:

- 1 Place the carafe onto a flat, clean surface. Place the filter on top of the carafe, and add up to 10 tablespoons (150ml) of fresh coffee grounds.

NOTE: Do not overfill.



- 2 Place the water chamber on top of the filter and turn the adjustable tab completely to the left to shut off the water flow. Fill up the water chamber with iced or room temperature water (max capacity 20 fl oz / 600ml).



- 3 Adjust the tab to your preferred water drop flow rate.

NOTE: 20 fl oz of water will take approximately from 5min to 75min to drip completely when set from fastest to slowest settings respectively.



- 4 Add the lid to the water chamber and allow the coffee or tea to cold brew at room temperature.



- 5 Once done, remove the water chamber and the filter, dispose of used coffee grounds, and rinse the filter well. Consume your cold brew immediately or cover the glass carafe with the lid and refrigerate.



CLEANING AND CARE

- 1 After brewing, remove the filter and discard of used coffee grounds or tea leaves.
 - 2 Rinse and wash all parts thoroughly with warm, soapy water. Rinse and set aside to air dry or dry each part with a clean, dry, and soft kitchen towel.
- NOTE:** Hand wash recommended! Carafe top-shelf dishwasher safe only.

TECHNICAL SPECIFICATIONS

Capacity:

Carafe: 47.3 fl oz / 1.4L
Water chamber: 20.3 fl oz / 600 ml
Filter: 10 tablespoons / 150 ml

Material:

Carafe: Borosilicate glass
Water chamber: AS plastic
Filter: Food-grade SS304
Lid & Water flow tab: PP plastic (BPA free)



Your purchase comes with a 100% satisfaction guarantee from Müller

If you are not happy with the product for any reason, please contact us at support@muellerdirect.com with your feedback or questions, and we will do our best to make things right for you!

Müller USA

168 Mason Way Unit #4A,
City of Industry, CA 91746
Telephone: (888) 632-9981
E-mail: support@muellerdirect.com
Web: www.muellerhome.us